































• Any linear, two-terminal network with dependent and independent sources can be represented by an equivalent circuit consisting of a single current source and a single parallel resistor representing the circuit from the VIEWPOINT of the circuits load.







































